

LANDMANN®

CROSSROADS CHIMINEA

Model 28251

ASSEMBLY INSTRUCTIONS



FOR SAFE OPERATION, PLEASE READ ALL ASSEMBLY AND OPERATING INSTRUCTIONS BEFORE USE.

REV. 3. 1/21/08



Model 28251

Congratulations on your purchase of the Crossroads Chiminea! At Landmann USA, our goal is to provide products that are easy to assemble and fun to use. Should you have questions, issues, a defective part or if you have any questions concerning its use, please contact us at:

customerservice@landmann-usa.com

-OR-

1-800-321-3473 M-F 8-5 Eastern Time

Proof of purchase may be required.

Landmann USA
Cartersville, GA 30120
www.landmann-usa.com

Made in China
© 2008 Landmann USA



READ FIRST! RULES FOR SAFE OPERATION

- THIS CHIMINEA IS FOR OUTDOOR USE ONLY!
- USE ONLY ON BRICK, CONCRETE, STONE OR OTHER MASONRY SURFACES.
- KEEP THE FIRE REASONABLE. A LARGE FIRE CAN DAMAGE OR SHORTEN THE LIFE OF THE CAST IRON.
- DO NOT USE FIREWOOD OVER 10" LONG IN THIS CHIMINEA.
- DO NOT USE ON LAWNS OR WOODEN DECKS.
- KEEP THE CHIMINEA AWAY FROM BUILDINGS, FLAMMABLE ITEMS AND VEHICLES.
- THE CHIMINEA IS FOR ADULT USE ONLY.
- DO NOT MOVE THE CHIMINEA WHILE IT IS BEING USED.
- DO NOT LEAVE UNATTENDED AT ANY TIME WHILE IN USE.
- DO NOT USE IN WINDY CONDITIONS.
- DO NOT OVERLOAD OR USE TO BURN LEAVES OR GARBAGE.
- KEEP THE SPARK SCREEN IN PLACE WHILE USING.
- USE CAUTION WHEN REMOVING THE SPARK SCREEN, AS HOT STEAM OR A FLARE UP COULD CAUSE BURNS.
- BEFORE EACH USE, MAKE SURE THE CHIMINEA IS IN GOOD WORKING CONDITION.
- USE CAUTION AFTER THE FIRE HAS BEEN EXTINGUISHED- SURFACES WILL REMAIN HOT FOR SOME TIME.
- BE SURE ALL COALS ARE COLD BEFORE EMPTYING. IF NECESSARY POUR WATER ON COALS.

